

Product Application Manual

PREPARE:

Wash the glass with a pH neutral soap.


DEGREASE:

Clean the glass surface with IPA. Dilute the IPA in 30% water. For example in a 1L bottle add 300ml water and 700ml IPA.

SUITABLE FOR:


✓ Glass

PRODUCT APPLICATION INSTRUCTIONS:



01


Gently shake the Clear View Bottle before use.



02

Open the lid and apply generous amount of coating on the dry/new applicator pad.

💡 **TIP:** Put the lid back on the bottle after applying on the applicator pad to stop the product from curing inside the bottle.



03


Work in cross-hatch pattern on small areas and make sure the coating is applied evenly.

💡 **TIP:** Apply the product generously on the applicator pad for even application. If there are streak marks on surface when applying add a few more drops on the pad and apply again.



04

Let the product dry for 1 minute and remove excess residue using a 380gsm microfibre cloth. Inspect the surface thoroughly after wiping off to ensure there are no haze marks.



05

Apply just one layer of glass coating and allow it to dry for at least 6 hours.